

OLYMPUS

OLYMPUS OPTICAL CO., LTD.

San-Ei Building, 22-2, Nishi-Shinjuku 1-chome, Shinjuku-ku, Tokyo, Japan. Tel. 03-340-2211

OLYMPUS CAMERA CORPORATION

Crossways Park, Woodbury, New York 11797, U.S.A. Tel. 516-364-3000

OLYMPUS OPTICAL CO.(EUROPA)GMBH

Postfach 104508, Wendenstrasse 14-16, 2 Hamburg 1, West Germany. Tel. 040-23773-0


OLYMPUS OPTICAL CO.(UK)LTD.

2-8 Hordwicks Street, London EC1Y 0TX, England. Tel. 01-253-2772


PRINTED IN JAPAN TELE23-1282-50MS

OLYMPUS XA2


INSTRUCTIONS ■ BEDIENUNGSANLEITUNG
MODE D'EMPLOI ■ INSTRUCCIONES




1. Uncap the battery chamber.
1. Batteriefachdeckel öffnen.
1. Ouvrir le compartiment à piles.
1. Abra el compartimento de pilas.




2. Insert batteries.
2. Batterien einsetzen.
2. Introduire les piles.
2. Inserte las pilas.




3. Check the batteries.
3. Batterien kontrollieren.
3. Contrôler les piles.
3. Compruebe la carga de las pilas.




4. Open the camera back.
4. Kamerarückwand öffnen.
4. Ouvrir le dos de l'appareil.
4. Abra la tapa posterior.




5. Load the film cartridge.
5. Filmpatrone einsetzen.
5. Charger le film.
5. Inserte la película.




6. Film magazine ready.
6. Filmfang einhängen.
6. Introduire l'amorce du film.
6. Inserte el guía de la película.




7. Engage the perforations of the film.
7. Engage las perforaciones de la película en los dientes.




8. Tighten the film.
8. Film straff ziehen.
8. Tendre le film.
8. Tense bien la película.




9. Close the camera back.
9. Kamerarückwand schließen.
9. Refermer le dos de l'appareil.
9. Cierre la tapa posterior.



10. Open the Dust Barrier fully.
10. Staubschutz voll öffnen.
10. Ouvrir à fond le protecteur.
10. Abra por completo la barrera.



11. Arm the camera.
11. Bildzählwerk einschalten.
11. Armer et déclencher jusqu'à ce que le "1" apparaisse.
11. Haga tomas en blanco hasta que el "1" se vea.



12. Set the ASA film speed.
12. ASA-Filmempfindlichkeit einstellen.
12. Ajuster la sensibilité ASA.
12. Ajuste la sensibilidad ASA.